



Kite Alive

True Wireless Earbuds



USER MANUAL



Specifications:

Model: Kite Alive

Bluetooth Version: 5.1

Speaker Driver: 10 mm

Earbuds Battery: 40 mAh*2

Charging Case Battery: 400 mAh

Frequency: 20Hz – 20,000 HZ

Impedance: 32Ω

Charging Voltage: DC 5V

Charging Time: 1.5 H

Water Resistance: IPX6

ANC Noise Reduction: 25dB ± 3 dB


Music Play Time (ANC ON): 4H

Music Play Time (ANC OFF): 5H

Getting Started:

Pairing and connecting

- 1.The Earbuds automatically pair to each other after taking them out of the charging case (after 1st successful connection).
- 2.One of the indicators will flash to blue light. The other one lights up red for 1 second and then the light goes out (in pairing mode).
- 3.Select “Kite Alive” from the device list in your Bluetooth list.



Controls:

L



Play / Pause



Previous Song / Answer Call / End Call



Volume Down



Activate Siri / Voice Assistant



3's ANC / Transparency Mode / Reject Call



5's Power On / Off

R



Play / Pause



Next Song / Answer Call / End Call



Volume Up



Activate Siri / Voice Assistant



3's ANC / Transparency Mode / Reject Call



5's Power On / Off

Turning On and Turning Off:

Turn On:


1. Open the cover of the charging box and take out the earbuds. The earbuds will power on automatically.

Turn Off:

1. Place the earbuds in the charging compartment and close the cover of the charging case.
2. The earbuds will turn off automatically.


Charge

CHARGING MODE



*Push back and forth to open and close the cover,
Putting the earphone in and out of the battery compartment

Charge



Note: Please charge the earbuds and the charging case at least once every 3 months when not in use for a long time. Otherwise, the battery may be damaged and cannot be used.

Earbuds Charging	When the earbuds are placed into the charging case, they turn off automatically and start charging (when only one earphone is placed in the charging case, the other will not turn off). The Red Light will stay on and change to blue when it is fully charged (The light turns off after 30 seconds)
Charging Case Charging	A. LED 1, LED 2, LED 3 and LED 4 are successively turned on (blue light). The four blue lights are on after being fully charged. When the charging case is disconnected, the power indicator light will go out after staying on for 3 seconds. B. The charging case indicator lights up in red when charging and goes out when fully charged.
Earbuds Low Battery	When the battery is low, there will be a prompt of "Low Battery, Please charge" and the Red light flashes slowly.

Truly Wireless Active Noise Cancellation Technology:

With the technology of True Wireless Earbuds, you can select compatible communication devices without using cables. Earbuds work with Bluetooth technology with maximum distance between the device and the earbuds not exceeding 10 metres (about 30 feet).

Using Active Noise Cancellation technology, the microphones collect the noise and then the ANC Chipset calculates the sound wave and generates a reverse sound wave that is opposite to the sound collected by the microphone. The sound and the reverse sound wave cancel each other eliminating unwanted outside noise.

Warranty and Support:

Kite Alive comes with a 1 year Brand Warranty from the original date of purchase. You need to register the device within 10 days from the original date of purchase in our official website to be eligible to avail the warranty.

For any queries or support, you can contact below:

Email ID: support@kitelifestyle.com

Website: www.kitelifestyle.com

Follow us on :



kite.flyhigh



Kite_FlyHigh



kite.flyhigh



www.kitelifestyle.com

RoHS
Compliant

